#### INTERCEPTOR MARINE MASTER PARTS AND ACCESSORIES CATALOG.

#### General Information.

When ordering parts, always give the complete part number and engine number. In the event the part number is not known the following information should be included:

- A. Complete description of part.
- B. Model, year and Horsepower.
- C. Dimension, number of teeth, size, etc.; if possible, rouch sketch of part.

## ENGINE NUMBER IDENTIFICATION.

#### prior to January 1, 1959

Model & Horsepower	Cubic Inch	Starting with numbers
125 135	239 256	2501 to 25116 25116 up
145	256	4501 to 45326
150	256	501 up
165	272	6001 to 60398
170	272	60398 up
185 215	292 312	7501 up 3501 up

Engine numbers are located as follows: Facing the Transmission end of the engine it is stamped below the right hand head, also on current production engines the serial numbers are stamped on the front cover above the tachometer drive housing. Engine number identification starting January 1, 1959 with engine #1.

Starting the first of the year we are incorporating a change in the numbering system of our engines where by we hope to be able to give you a description of the engine if you have available only the numbers which will be stamped in our usual location on the front cover of the engines except 361 cubic inch, where marks are stamped at rear of the block on the right bank.

#### GENERAL INFORMATION.

The following will show you examples of marking and give you the equipment listings you will need for interpretation.

# Effective January 1, 1959

A 256 - 1 B 256 - 2	150	H.P. H.P.			ndard osite	L.I R.I		1959 1959
C 272 D 292 E 312	185	H.P. H.P. H.P.						
			v č	2 4 Ř	9 127			
SEE CODE SHEETS	1					SEI	RIAL	NUMBER
V DRIVE ENGINES			1961	Model	Engines Engines Engines	Are	Numb	ered l

### EXAMPLES.

C 2 4 R 9 1 2 7	170 H.P. with Warner 1 1/2:1 Red - Sherwood Water Pumps - Micro Mounts - Opposite Rotation Serial #127.
E 3 L 9 1 2 8	215 H.P. with Dearbo 1 1/4:1 Red - Sherwood Water Pump - Special Mounts - Mallory Ignition Standard Rotation - Serial #128.

<sup>\*\*</sup> When ordering parts for right or left hand, view engine from flywheel end.